


RVP – Dashboard

When you log on, the below Dashboard is the landing page. The Dashboard is for viewing only: No actions can be performed from this page



Navigating the Dashboard

Hold/Misc: Cars your facility requested to be placed on HOLD

ETA: Feature not available

Bad Ordered Equipment: Equipment marked as bad order in our TMS system

Inventory: See cars enroute to the serving RR, Inbound to your facility, On hand at your facility, and Outbound from your facility

Dwell Time: Railcars idle for a specific duration

Storage Equipment Status: Number of cars placed in storage on your serving railroad

Net Tons: Net tonnage in pipeline